

## **Operating Instructions for Summit SC Oxygen SCT32 & SCT42 Task Chairs.**

All adjustments should be made whilst seated.

1. The overall height of the chair is adjusted by lifting the lever located below the front of the seat on the right-hand side. Lift your weight off the chair allowing it to rise and release the lever at the desired height. To lower the seat simply lift the lever, put your weight back on the seat and release at the desired height.
2. The synchronised recline of the seat and back is unlocked by lifting the lever located below the front of the seat on the left-hand side. Please be aware that there is a safety feature that requires you to lean gently into the back before it will release. The back can be locked in any of five positions by pushing the lever down or left unlocked to follow your movements. The tension of the recline is adjusted by turning the knob located under the front of the seat.
3. The lumbar support can be moved up or down as required.
4. The height adjustable arms have a trigger underneath to lock the arm at the required height. The pads can be rotated to point inwards. The width of the arms can be changed by unlocking the handwheels under the seat and relocating arms in new position.
5. When fitted with a headrest this can be adjusted by lifting up and rotating as required.