

Operating Instructions For Summit Chairs SC Ergonomic Task Chairs Models SCT92, SCT102, & SCT112.

All adjustments should be made whilst you are seated.

1. The seat depth can be adjusted by lifting the lever located below the front of the seat on the right-hand side. Slide the seat forwards or backwards until the required position is achieved and release the lever to lock the seat in place.
2. The overall height of your chair can be adjusted by twisting clockwise the lever located below the middle of the seat on the right-hand side. Lift your weight off the chair allowing it to rise and release the lever at the desired height. To lower the chair simply put your weight back onto the seat, twist the lever and release it at the required height.
3. The synchronised recline of the seat and back is locked and unlocked by pressing in and releasing the grey button located in the centre of the height adjustment lever. Please be aware that there is a safety feature that requires you to lean gently into the back of the chair before it will release. The seat and back can be locked into any one of six positions or it can be left unlocked to follow your movements. The tension of the recline is adjusted by turning the knob located under the front of the seat.
4. The back height can be adjusted by directly lifting the back up a step at a time until the correct positioning of the lumbar support is achieved. When the back reaches the top of its travel it will then drop back to the start position.
5. The inflatable lumbar support can be adjusted by using the hand bulb that hangs under the left-hand side of the seat. Squeeze the bulb to inflate the support and press the button on the bulb to deflate it.
6. Both arms can be adjusted for height by pressing the buttons located under the plastic body of each arm and lifting them to the required positions.