

Operating Instructions for Summit SC Ergonomic, SCT61, SCT71 & SCT81 Operator Chairs Manufactured after January 2006.

All adjustments should be made whilst you are seated.

1. The overall height of your chair can be adjusted by lifting the lever located below the middle of the seat on the right-hand side. Lift your weight off the chair allowing the seat to rise and release the lever at the required height. To lower the chair, simply lift this lever, put your weight back onto the seat and release the lever at the required height.
2. The seat angle can be adjusted by lifting the middle one of the three levers located below the back of the seat on the right-hand side. The seat can be locked at the required angle by pushing the lever down or it can be left unlocked to follow user's movements. The tension of the recline can be adjusted by turning the knob located under the front of the seat.
3. The back angle of the chair can be adjusted independently of the seat by lifting the rear lever. The back can be locked into the desired position by pushing this lever down or it can be left unlocked to follow user's movements.
4. The back height can be adjusted by directly lifting the back up a step at a time until the correct positioning of the lumbar support is achieved. When the back reaches the top of its travel it will drop back to the start position.
5. The height adjustable arms have levers located underneath the outside edge of each arm pad. To adjust the arm heights, lift each lever in turn, set each arm at the required position and release the levers to lock the arms in place.