

Operating Instructions for Summit Rialto RL22 Chairs.

All adjustments should be made whilst seated.

1. The overall height of your chair can be adjusted by lifting the lever located below the front of the seat on the right hand side. Lift your weight off the chair allowing it to rise and release the lever at the desired height. To lower the chair simply lift the lever, put your weight onto the seat and release the lever at the required height.
2. The synchronised recline of the seat and chair back can be adjusted by lifting the lever located below the front of the seat on the left-hand side. Please be aware that there is a safety feature that requires you to lean gently into the back of the chair before it will release. The seat and back can be locked into any one of five positions by pushing the lever down or they can be left unlocked to follow your movements. The tension of the recline can be adjusted by turning the knob located under the front of the seat.
3. The back height can be adjusted by directly lifting the chair back up a step at a time until the correct positioning of the lumbar support is achieved. When the back reaches the top of its travel it will then drop back to the start position.
4. The inflatable lumbar support can be adjusted using the hand bulb that hangs under the left-hand side of the seat. Squeeze the bulb to inflate the support and press the button on the bulb to deflate it.
5. The height adjustable arms have levers located underneath the outside edge of each arm pad. To adjust the arms, lift up each lever in turn, set the arms at the desired position and release the levers to lock the arms in position.
6. If your chair is fitted with a seat slider the seat depth can be adjusted by lifting the lever located below the middle of the seat on the left-hand side. Slide the seat forwards or backwards and release the lever to lock the seat in the desired position.